When the bell is not in use these two discs remain apart, but directly the button is pushed it brings B into contact

with A and the bell rings.